


# Visseuse à batterie DM540

NO.	PARTS NAME	Q
1	METAL RING	1
2	GEAR BOX ASS'Y	1
3	HIGH/LOW SPEED ROD	1
4	SCREW	2
5	MOTOR CONNECTOR	1
6	MOTOR ASS'Y	1
7	FRONT COVER ASS'Y	1
8	SCREW	2
9	HOUSING SCREW	2
10	SPRING	2
11	PIVOT	2
12	PIVOT	2
13	MAIN SWITCH	1
14	SWITCH KNOB	1
15	SWITCH LOCK KNOB	1
16	HOUSING-L&R	1
17	SPINDLE	1
18	HOUSING SCREW	1
19	HOUSING FIXTURE	2
20	HOUSING LABEL-R	1
21	BATTERY PACK	1
22	BATTERY LABEL	1
23	BATTERY WARNING LABEL	1
24	CHARGER	1
25	POWER CORD	1
26	CHARGER UPPER LABEL	1
27	CHARGER LOWER LABEL	1



\*pièces d'usure